



## Model FS4200A Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
1	158876-0	LOCATOR L COMPLETE	1	PC.
2	424163-2	DUST SEAL SLEEVE	1	PC.
3	424235-3	SEAL RING 30	1	PC.
4	450881-6	LOCK RING	1	PC.
5	233974-2	RING SPRING 33	1	PC.
6	232245-4	LEAF SPRING	1	PC.
7	266361-0	TAPPING SCREW 4X30	3	PC.
8	158880-9	GEAR HOUSING HNB COMPLETE	1	PC.
9	232050-9	LEAF SPRING	1	PC.
10	216001-0	STEEL BALL 3.5	1	PC.
11	324983-3	SPINDLE 125N	1	PC.
16	233126-5	COMPRESSION SPRING 6	1	PC.
17	268229-6	COLLARED PIN 8	1	PC.
18	226687-2	HELICAL GEAR 41N	1	PC.
19	216415-3	THRUST NEEDLE GAUGE 821	1	PC.
20	216212-7	WASHER 821	1	PC.
21	424162-4	SEAL RING	1	PC.
22	158874-4	GEAR HOUSING COVER COMPLETE	1	PC.
23	451099-2	RING 7	1	PC.
24	210007-0	BALL BEARING 608VV	1	PC.
25	240083-0	FAN 52	1	PC.
26	515756-7	ARMATURE ASSEMBLY 115V	1	PC.
	D10	INC. 23-25,27,28		
27	681636-0	INSULATION WASHER	1	PC.
28	210062-2	BALL BEARING 607ZZ	1	PC.
29	421868-5	LABYRINTH RUBBER RING 19	1	PC.
30	266467-4	TAPPING SCREW 4X50	2	PC.
31	450880-8	BAFFLE PLATE	1	PC.
32	633691-8	FIELD 115V	1	PC.
33	450877-7	MOTOR HOUSING S	1	PC.
34	162272-6	HOOK	1	PC.
35	867324-5	FS4200A NAME PLATE	1	
36	808575-1	4000RPM INDICATION LABEL	1	PC.
37	689111-0	SPACER	2	PC.
38	195007-0	CARBON BRUSH CB-407	1	PC.
39	643948-9	BRUSH HOLDER	1	PC.
40	643951-0	BRUSH HOLDER	1	PC.
41	687123-7	STRAIN RELIEF	1	PC.
42	650614-1	SWITCH	1	PC.
43	158877-8	HANDLE COVER S COMPLETE	1	PC.
	C10			
44	263002-9	RUBBER PIN 4	2	PC.
44	266374-1	TAPPING SCREW 4X25	1	PC.
45	266374-1	TAPPING SCREW 4X25	2	PC.
46	631938-4	LIGHT CIRCUIT	1	PC.
49	265995-6	TAPPING SCREW 4X18	2	PC.
50	682559-5	CORD GUARD 8	1	PC.
51	664899-3	POWER SUPPLY CORD	1	PC.
52	819349-5	CLEAR LABEL	1	PC.
53	423413-2	RUBBER PLATE	1	

A01	784211-B	#2 PHILLIPS INSERT BIT (10/PK)	2 PC.
A02	784801-1	MAGNETIC BIT HOLDER 6.35-76	1 PC.
D01	654121-6	TAB	4 PC.
D02	654593-5	SPLICE	6 PC.