



Model LXNJ01 / LXNJ01Z Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	266048-4	TAPPING SCREW 4X40	4	PC.
002	141878-3	GEAR HOUSING COMPLETE	1	PC.
	C10 800P78-7	INDICATION LABEL	1	
003	331438-1	ROD	1	PC.
004	212222-2	NEEDLE BEARING 1612	1	PC.
005	326249-7	CRANK SHAFT	1	PC.
006	227314-4	SPUR GEAR 31	1	PC.
007	253215-0	FLAT WASHER 8	1	PC.
008	254002-0	WOODRUFF KEY 3	1	PC.
009	267133-6	FLAT WASHER 6	1	PC.
010	226158-9	GEAR COMPLETE 16-36	1	PC.
011	266026-4	TAPPING SCREW BIND CT 4X12	1	PC.
012	344116-4	STOPPER	1	PC.
013	256111-1	PIN 6	1	PC.
014	322703-9	RAM	1	PC.
015	322702-1	PUNCH HOLDER	1	PC.
016	265880-3	H.S.SET SCREW(CONE POINT)M5X8	1	PC.
017	A-83951	PUNCH	1	PC.
018	A-15051	DIE	1	PC.
019	322701-3	DIE HOLDER	1	PC.
020	266080-8	HEX. SOCKET HEAD BOLT M3X12	2	PC.
021	322748-7	LOCK NUT	1	PC.
022	442191-5	GASKET	1	PC.
023	141877-5	GEAR HOUSING COVER COMPLETE	1	PC.
	C10 213961-7	O RING 22	1	PC.
024	619312-6	ARMATURE	1	PC.
025	631714-6	LED CIRCUIT	1	PC.
026	638376-1	YOKE UNIT	1	PC.
027	638448-2	ENDBELL COMPLETE	1	PC.
028	814B75-3	LXNJ01 NAME PLATE	1	
029	265995-6	TAPPING SCREW 4X18	5	PC.
030	419566-3	SWITCH KNOB	1	PC.
031	188736-2	HOUSING SET	1	SET
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 36		
032	419519-2	SWITCH LEVER	1	PC.
033	650579-7	SWITCH 1246.3223	1	PC.
034	620072-5	CONTROLLER	1	PC.
035	643838-6	TERMINAL	1	PC.
036	188736-2	HOUSING SET	1	SET
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 31		
037	CB430	CARBON BRUSH CB-430 (195018-5)	1	SET
038	643929-3	BRUSH HOLDER CAP	2	PC.
039	419518-4	HOLDER CAP COVER	2	PC.
A01	781028-4	WRENCH 32	1	PC.
A02	783208-8	HEX. WRENCH 2.5	1	PC.
E01	810531-9	CAUTION LABEL	1	PC.
	***DC18RA	DC18RA FAST CHARGER	1	PC. (LXNJ01)
	BL1830	BATTERY BL1830 SET (195324-8)	2	SET (LXNJ01)
	450128-8	BATTERY COVER	1	PC. (LXNJ01)
	821016-X	TOOL BAG	1	(LXNJ01)