


Modelo TM30D CORDLESS MULTI TOOL



Pieza	Código	Descripción	Info	CTD.	N/O	Opc. 1	Opc. 2	OBS.
001	266429-2	TAPPING SCREW 3X16		12				
002	183E32-3	MOTOR HOUSING SET		1				
C10	263039-6	RUBBER PIN 4		3				
C20	424859-5	CUSHION		2				
D10		INC. 28						
003	852E51-7	TM30D NAME PLATE		1				
004	962151-6	RETAINING RING R-32		1				
005	253368-5	WASHER 16		1				
006	210147-4	BALL BEARING 6902		1				
007	326719-6	CRANK SHAFT		1				
008	456788-4	SPACER 21		1				
009	210147-4	BALL BEARING 6902		1				
010	210144-0	SPHERE BEARING 505		1				
011	961008-8	RETAINING RING S-5		1				
015	144085-7	CRANK HOUSING COMPLETE		1				
016	213987-9	O-RING 25		1				
017	213021-5	O RING 5		1				
018	224455-7	OUTER FLANGE 22		1				
019	266783-4	HEX.SOCKET C.S.H.SCREW M6X20		1				
020	456791-5	SWITCH KNOB		1				
021	424833-3	SPACER		1				
022	629220-3	DC MOTOR		1				
023	424467-2	CAP		1				
024	651610-2	SWITCH		1				
025	424860-0	SWITCH COVER		1				
026	620522-0	CONTROLLER		1				
C10	620543-2	LED CIRCUIT		1				
027	644813-5	TERMINAL		1				
028	183E32-3	MOTOR HOUSING SET		1				
C10	263039-6	RUBBER PIN 4		3				
C20	424859-5	CUSHION		2				
D10		INC. 2						
A01	783233-9	HEX. WRENCH 5		1				
A02B	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02C	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02D	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02E	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
A02F	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02G	143644-4	PLASTIC CASE COMPLETE		1				

Pieza	Código	Descripción	Info	CTD.	N/O	Opc. 1	Opc. 2	OBS.
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A03B	456128-6	BATTERY COVER		1				
A03C	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A03D	456128-6	BATTERY COVER		1				
A03E	196271-6	ADAPTER A SET		1				
A03F	456128-6	BATTERY COVER		1				
A03G	196271-6	ADAPTER A SET		1				
A04B	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A04C	B-21565	ABRASIVEPAPER DELTARED LONG60		1				
A04D	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A04E	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A04F	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A04G	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A05B	197412-7	BATTERY BL1016 SET		2				
A05C	B-21593	ABRASIVEPAPER DELTARED LONG12		1				
A05D	197414-3	BATTERY BL1021B SET		2				
A05E	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A05F	197417-7	BATTERY BL1041B SET		2				
A05G	B-21331	SEGMENT SAW BLADE 85 TMA007		1				
A06C	B-22931	ABRASIVEPAPER DELTARED LONG24		1				
A06E	B-21537	SANDING PAD		1				
A06G	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A07C	B-21537	SANDING PAD		1				
A07E	821538-0	TOOL BOX		1				
A07G	B-21369	PLUNGE CUT SAW BLADE 32 TMA010		1				
A08C	821538-0	TOOL BOX		1				
A08G	B-21381	PLUNGE CUT SAW BLADE 32 TMA012		1				
A09C	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A09E	456128-6	BATTERY COVER		1				
A09G	B-21428	PLUNGE CUT SAW BLADE 20 TMA016		1				
A10C	456128-6	BATTERY COVER		1				
A10E	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A10G	B-21434	PLUNGE CUT SAW BLADE 10 TMA017		1				
A11C	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A11E	197414-3	BATTERY BL1021B SET		2				
A11G	B-21456	SCRAPER 52 FLEXIBLE TMA019		1				
A12C	197412-7	BATTERY BL1016 SET		2				
A12G	B-21490	HM SEG SAW BLADE 85 TMA023		1				
A13G	B-21509	HM SEG SAW BLADE 65 TMA024		1				
A14G	B-21624	ABRASIVEPAPER DELTA RED 60		1				

